

FOOT PEDAL VALVE



PRODUCT TYPE

Combination pedal valve

FEATURES & SPECIFICATIONS

- Polished chrome plated finish
- Solid brass construction
- Short metal pedals indexed "H" and "C"
- NAIADTM self closing renewable cartridge
- Two 1/2" NPT female back inlets
- One 3/8" NPT female back outlet

PERFORMANCE SPECIFICATION

- Rated Operating Pressure: 20-125 PSI
- Rated Operating Temperature: 40 - 140o F

WARRANTY

- Lifetime Limited Faucet Warranty
- 5-Year Limited Cartridge Warranty
- 1-Year Limited Finish Warranty

COMPLIANT TO

- ASME A112.18.1M
- CSA B125
- NSF 61, Sec. 9

ARCHITECT/ENGINEER SPECIFICATION

Polished chrome plated solid brass construction, short metal pedals with "H" & "C" debossed on top. NAIADTM self-closing renewable cartridge. Two 1/2" NPT female back inlets, one 3/8" NPT female back outlet. This product is tested and certified to industry standards: ASME A112.18.1, NSF 61, Sec. 9 and CSA B125.

OPERATION AND MAINTENANCE

Installation should be in accordance with local plumbing codes. Flush all pipes thoroughly before installation. After installation, remove spout outlet or flow control and flush faucet thoroughly to clear any debris. Care should be taken when cleaning this product. Do not use abrasive cleaners, chemicals or solvents as they can result in surface damage. Use mild soap and warm water for cleaning and protecting the life of the product.

