

4" SWIVEL STEM CASTER WITH BRAKE

Swivel casters with 4 inch thermoplastic rubber wheel featuring Total Lock braking and zinc plated finish. Total Lock brake solidly locks both the swivel and wheel, providing an exceptionally sturdy base when engaged.

Wheels roll smoothly with integrated ball bearing design. The thermoplastic rubber wheel performs well on most surfaces, and excels on hard surfaces like tile and wood. Unlike black rubber wheels, they will not mark or mar floor surfaces.



SPECIFICATIONS

Wheel Size:	4" x 1 1/4"
Threaded Stem:	1/2" - 13 x 1 1/2"
Mounting Height	5 1/8"
Capacity (per caster):	250 pounds

The Stem Caster is used for Teclab TES (Tube-steel) Workbenches.

A Threaded Insert is used to secure the casters to the workbench.

